

PSD2Outbound GCO Alert-Istio 5xx Internal Server Error for Sealhub

PSD2Outbound GCO Alert-Istio 5xx Internal Server Error for Sealhub

Why do we have this alert?

- To notify if the service mesh has encountered an internal server error.

What does this alert mean?

For early detect of Issues in Istio.

Impact to customer-

- It will affect the currently processing as well as incoming requests.

Investigation Steps-

- Click on the link provided in the email to access the logs in Google Console.
- Verify the alert timestamp, severity, and affected resources.
- Analyze the error messages available in the alert
- Collect additional logs by searching in DB with the affected ids.

Verification Steps-

- Once alert is received ,check the request_id,CA_ID,audit_id and check requests failing in GCO alert.
- select * from sealhub_db.audit_log where audit_id='#####';
- We can report this issue respective team, also need to monitor closely.
- We can check in Database for latest success request to confirm if the issue is resolved or not.

Additional Information-

Contact list - [Contact List](#)